



PO BOX 56-2525 Pinecrest, FL 33256-2525 Tel: 305-253-8387

Fax: 786-345-0621 Email: info@fobis.com Web: www.weemote.com

## weemote@ dV Remote Control



WE-10

## **Key Features:**

- Simple User Interface
- Great for menu navigation interfaces such as those found in DVD. DVR and Video on Demand devices
- All buttons are learnable
- Small comfortable form factor with cushioned side band
- Hidden program buttons
- Protected Settings
- Strong ABS Plastic Construction
- Secured Cover will not break or pop-off
- Designed for supplemental needs works with existing remote controls

The weemote® dV Remote Control makes using devices with navigational menus such as DVD and DVR players easy to operate. Primarily designed for DVD players, the weemote® dV offers a simple and clean interface for basic operation.

It's a perfect compliment to use with our weemote® X TV Remote Control. Use the weemote® X to control line TV viewing while using the weemote® dV to access and control recorded or streaming video content.

It's great for young children using DVD titles that involve user interaction. Many popular DVD titles are loaded with interactive features. With only the buttons needed for onscreen menu navigation, the weemote® dV makes it easy for any user to enjoy all types of content without interruption.


Along with an extensive library of DVD codes, the weemote® dV also features a fully learnable interface for all buttons. The learning interface allows you to setup your weemote® dV with other devices such as DVR's, Internet TV, Apple TV, and many other video content appliances.Please note that learning may not work with certain devices, especially auto or RV DVD systems.

Housed in durable casing with a sleek, elegant design to promote comfort and support. The design of the case enables tabletop use that can used on a flat surface. The weemote dV also features a secured battery and program door to ensure the batteries and program settings stay in place.

## **Technical Specifications**

Physical	<ul> <li>5.5 " High X by 2.56" Wide by 1.5" Thick</li> <li>Handheld or Tabletop Use</li> <li>Weight 4 oz</li> <li>Batteries - 2 AAA (not included)</li> <li>Requires small philips head screwdriver to remove battery/program cover (not included)</li> </ul>
Retail Packaging	<ul> <li>weemote® dV</li> <li>Quickstart Guide</li> <li>Plastic Insert - 7.5" X 10.5"</li> </ul>
Setup Modes	<ul><li>Embedded Library of DVD Codes</li><li>Learning Mode for all buttons</li></ul>
Basic Controls	Stop, Play, Pause, Navigation: Up, Down, Right and Left, Enter/OK and Menu
Advanced Controls	Via Learning Modes - Any control/s from your existing remote to any button on the weemote® dV

## **Diagrams**



**Program Covers** 

