

Brand	Device_Type	Code_Number
Emerson		297
AT & T	Cable Box	115
AMERICAST	Cable Box	128
EAGLE	Cable Box	6
EASTERN	Cable Box	7
EASTERN	Cable Box	15
GENERAL	Cable Box	1
GENERAL	Cable Box	3
GENERAL	Cable Box	5
GENERAL	Cable Box	49
GENERAL	Cable Box	55
GENERAL	Cable Box	75
GENERAL	Cable Box	109
GENERAL	Cable Box	115
GENERAL	Cable Box	121
GENERAL	Cable Box	122
GENERAL	Cable Box	134
GENERAL	Cable Box	183
GENERAL	Cable Box	196
GENERAL	Cable Box	197
GENERAL	Cable Box	200
GENERAL	Cable Box	201
GENERAL	Cable Box	202
GENERAL	Cable Box	203
GENERAL	Cable Box	220
GENERAL	Cable Box	247
GENERAL	Cable Box	248
GENERAL	Cable Box	249
GENERAL	Cable Box	250
GENERAL	Cable Box	251
GENERAL	Cable Box	252
GENERAL	Cable Box	254
HAMLIN	Cable Box	88
HAMLIN	Cable Box	89
HAMLIN	Cable Box	90
HITACHI	Cable Box	53
HITACHI	Cable Box	124
HITACHI	Cable Box	132
HITACHI	Cable Box	220
HYUNDAI	Cable Box	127
JERROLD	Cable Box	1
JERROLD	Cable Box	50
JERROLD	Cable Box	52
JERROLD	Cable Box	53
JERROLD	Cable Box	55
JERROLD	Cable Box	75
JERROLD	Cable Box	115
JERROLD	Cable Box	120

Brand	Device_Type	Code_Number
JERROLD	Cable Box	122
JERROLD	Cable Box	200
JERROLD	Cable Box	220
MACOM	Cable Box	44
MACOM	Cable Box	187
MOTOROLA	Cable Box	1
MOTOROLA	Cable Box	3
MOTOROLA	Cable Box	5
MOTOROLA	Cable Box	49
MOTOROLA	Cable Box	55
MOTOROLA	Cable Box	75
MOTOROLA	Cable Box	109
MOTOROLA	Cable Box	115
MOTOROLA	Cable Box	121
MOTOROLA	Cable Box	122
MOTOROLA	Cable Box	134
MOTOROLA	Cable Box	183
MOTOROLA	Cable Box	196
MOTOROLA	Cable Box	197
MOTOROLA	Cable Box	200
MOTOROLA	Cable Box	201
MOTOROLA	Cable Box	202
MOTOROLA	Cable Box	203
MOTOROLA	Cable Box	220
MOTOROLA	Cable Box	247
MOTOROLA	Cable Box	248
MOTOROLA	Cable Box	249
MOTOROLA	Cable Box	250
MOTOROLA	Cable Box	251
MOTOROLA	Cable Box	252
MOTOROLA	Cable Box	254
NEC	Cable Box	10
NSC	Cable Box	20
OAK	Cable Box	56
OAK	Cable Box	57
OAK	Cable Box	58
OAK	Cable Box	59
PACE	Cable Box	11
PANASONIC	Cable Box	14
PANASONIC	Cable Box	60
PANASONIC	Cable Box	61
PANASONIC	Cable Box	99
PANASONIC	Cable Box	157
PANASONIC	Cable Box	177
PIONEER	Cable Box	2
PIONEER	Cable Box	62
PIONEER	Cable Box	64
PIONEER	Cable Box	68

Brand	Device_Type	Code_Number
PIONEER	Cable Box	111
PULSAR	Cable Box	65
RADIO SHACK	Cable Box	23
RADIO SHACK	Cable Box	131
REGAL	Cable Box	89
REGAL	Cable Box	90
REGENCY	Cable Box	7
SL-MARX	Cable Box	7
SAMSUNG	Cable Box	6
SAMSUNG	Cable Box	65
SCIENTIFIC	Cable Box	3
SCIENTIFIC	Cable Box	66
SCIENTIFIC	Cable Box	67
SCIENTIFIC	Cable Box	68
SCIENTIFIC	Cable Box	69
SIGNAL	Cable Box	6
SIGNATURE	Cable Box	53
SIGNATURE	Cable Box	220
SKYCABLE	Cable Box	129
SONY	Cable Box	24
SPRUCER	Cable Box	14
SPRUCER	Cable Box	60
STARCOM	Cable Box	55
STARCOM	Cable Box	200
STARCOM	Cable Box	201
STARGATE	Cable Box	7
STARGATE	Cable Box	22
STARGATE	Cable Box	65
STARGATE	Cable Box	163
SYLVANIA	Cable Box	72
TEXSCAN	Cable Box	72
TOCOM	Cable Box	73
TOCOM	Cable Box	74
TOCOM	Cable Box	75
VIDEOWAY	Cable Box	5
VIEWSTAR	Cable Box	20
VIEWSTAR	Cable Box	185
ZENITH	Cable Box	5
ZENITH	Cable Box	118
TELUS	Cable Box	256
Motorola Moxi	Cable Box	268
Samsung	Cable Box	270
SCIENTIFIC	Cable Box	68
Scientific Atlanta	Cable Box	272
SKYCABLE	Cable Box	129
Samsung	Cable Box	23
Comcast DTA	Cable Box	308
Comcast	Cable Box	307

Brand	Device_Type	Code_Number
RCA ULTIMATE	DIGITAL VIDEO	118
REPLAYTV	DIGITAL VIDEO	31
REPLAYTV	DIGITAL VIDEO	157
SHOWSTOPPER	DIGITAL VIDEO	157
SONY ULTIMATE	DIGITAL VIDEO	114
Hughes	DIGITAL VIDEO	30
Access HD	DTV	283
Artec	DTV	284
Channel Master	DTV	285
COSHIP	DTV	286
Digital Stream	DTV	287
GE	DTV	288
Goodmind	DTV	289
Insignia	DTV	290
Lasonic	DTV	291
Magnavox	DTV	292
Magnavox	DTV	293
Microgem	DTV	294
RCA	DTV	295
Sansonic	DTV	296
Skardin	DTV	297
Tivax	DTV	298
Philco	DTV	293
Zentech	DTV	297
Zenith	DTV	290
Zenith	DTV	290
Dish	DTV	302
Apex	DTV	305
Apex	DTV	124
TIVO	DVR	30
TIVO	DVR	32
TIVO	DVR	33
TIVO	DVR	151
TIVO/PHILIPS	DVR	151
TIVO/SONY	DVR	162
Motorola	DVR	115
Amino	IPTV	269
I3	IPTV	269
Verizon FOIS	IPTV	001
Verizon	IPTV	276
Scientific Atlanta	IPTV	275
AT&T	IPTV	280
ADB3800	IPTV	281
SkyAngel	IPTV	302
Amino	IPTV	277
Entone	IPTV	301
Motorola	IPTV	280
Cisco	IPTV	280

Brand	Device_Type	Code_Number
Amino	IPTV	282
Amino	IPTV	282
Telus	IPTV	280
ALPHASTAR	Sattelite Receiver	125
AMWAY	Sattelite Receiver	139
AMWAY	Sattelite Receiver	143
BIRDVIEW	Sattelite Receiver	235
CI SATELLITE	Sattelite Receiver	146
CABLE	Sattelite Receiver	183
CENTURY	Sattelite Receiver	148
CHANNEL	Sattelite Receiver	147
CHANNEL	Sattelite Receiver	187
CHAPARRAL	Sattelite Receiver	214
CHAPARRAL	Sattelite Receiver	215
CHAPARRAL	Sattelite Receiver	216
CHAPARRAL	Sattelite Receiver	217
CHEYENNE	Sattelite Receiver	216
CITOH	Sattelite Receiver	145
CONIFER	Sattelite Receiver	142
CURTIS MATHES	Sattelite Receiver	174
DISHPLAYER	Sattelite Receiver	100
DISHPLAYER	Sattelite Receiver	101
DX ANTENNA	Sattelite Receiver	213
DX ANTENNA	Sattelite Receiver	144
DX ANTENNA	Sattelite Receiver	146
DX ANTENNA	Sattelite Receiver	258
DX	Sattelite Receiver	121
DX	Sattelite Receiver	144
DirecTV	Sattelite Receiver	93
DirecTV	Sattelite Receiver	94
DirecTV	Sattelite Receiver	95
DirecTV	Sattelite Receiver	96
DirecTV	Sattelite Receiver	97
DirecTV	Sattelite Receiver	98
DirecTV	Sattelite Receiver	124
DirecTV	Sattelite Receiver	132
DISH NETWORK	Sattelite Receiver	100
DISH NETWORK	Sattelite Receiver	101
DISH NETWORK	Sattelite Receiver	119
DRAKE	Sattelite Receiver	149
DRAKE	Sattelite Receiver	187
DRAKE	Sattelite Receiver	188
DRAKE	Sattelite Receiver	189
DRAKE	Sattelite Receiver	191
DRAKE	Sattelite Receiver	194
EHOSTAR	Sattelite Receiver	113
EHOSTAR	Sattelite Receiver	119
EHOSTAR	Sattelite Receiver	137

Brand	Device_Type	Code_Number
EHOSTAR	Sattelite Receiver	150
EHOSTAR	Sattelite Receiver	204
EHOSTAR	Sattelite Receiver	205
EHOSTAR	Sattelite Receiver	206
EHOSTAR	Sattelite Receiver	207
EHOSTAR	Sattelite Receiver	208
EHOSTAR	Sattelite Receiver	209
EXPRESS VU	Sattelite Receiver	119
FUJITSU	Sattelite Receiver	186
FUJITSU	Sattelite Receiver	259
GENERAL	Sattelite Receiver	1
GENERAL	Sattelite Receiver	3
GENERAL	Sattelite Receiver	5
GENERAL	Sattelite Receiver	49
GENERAL	Sattelite Receiver	55
GENERAL	Sattelite Receiver	75
GENERAL	Sattelite Receiver	121
GENERAL	Sattelite Receiver	122
GENERAL	Sattelite Receiver	134
GENERAL	Sattelite Receiver	183
GENERAL	Sattelite Receiver	196
GENERAL	Sattelite Receiver	197
GENERAL	Sattelite Receiver	200
GENERAL	Sattelite Receiver	201
GENERAL	Sattelite Receiver	202
GENERAL	Sattelite Receiver	203
GENERAL	Sattelite Receiver	220
GENERAL	Sattelite Receiver	247
GENERAL	Sattelite Receiver	248
GENERAL	Sattelite Receiver	249
GENERAL	Sattelite Receiver	250
GENERAL	Sattelite Receiver	251
GENERAL	Sattelite Receiver	252
GENERAL	Sattelite Receiver	254
HITACHI	Sattelite Receiver	124
HITACHI	Sattelite Receiver	132
HEMOCABLE	Sattelite Receiver	226
HOUSTON	Sattelite Receiver	113
HUGHES	Sattelite Receiver	93
HUGHES	Sattelite Receiver	94
HUGHES	Sattelite Receiver	95
HUGHES	Sattelite Receiver	96
HUGHES	Sattelite Receiver	97
HUGHES	Sattelite Receiver	98
HUGHES	Sattelite Receiver	124
HUGHES	Sattelite Receiver	132
IQ	Sattelite Receiver	212
INSIGHT	Sattelite Receiver	124

Brand	Device_Type	Code_Number
INTERSAT	Sattelite Receiver	143
INTERSAT	Sattelite Receiver	241
JVC	Sattelite Receiver	100
JVC	Sattelite Receiver	101
JVC	Sattelite Receiver	119
JANEIL	Sattelite Receiver	178
JANEIL	Sattelite Receiver	186
KATHREIN	Sattelite Receiver	260
KENWOOD	Sattelite Receiver	243
LEGEND	Sattelite Receiver	137
LEGEND	Sattelite Receiver	204
MACOM	Sattelite Receiver	134
MACOM	Sattelite Receiver	174
MACOM	Sattelite Receiver	261
MAGNAVOX	Sattelite Receiver	40
MAGNAVOX	Sattelite Receiver	117
MAGNAVOX	Sattelite Receiver	126
MEMOREX	Sattelite Receiver	117
MEMOREX	Sattelite Receiver	137
NEXT WAVE	Sattelite Receiver	212
NORSAT	Sattelite Receiver	142
ORB	Sattelite Receiver	140
PANASONIC	Sattelite Receiver	123
PANASONIC	Sattelite Receiver	178
PANSAT	Sattelite Receiver	246
PERSONAL	Sattelite Receiver	262
PHILIPS	Sattelite Receiver	16
PHILIPS	Sattelite Receiver	117
PHILIPS	Sattelite Receiver	126
PHILIPS	Sattelite Receiver	176
PICO	Sattelite Receiver	139
PL	Sattelite Receiver	140
PL	Sattelite Receiver	222
PRESIDENT	Sattelite Receiver	179
PRESIDENT	Sattelite Receiver	263
PRIMESTAR	Sattelite Receiver	49
PRIMESTAR	Sattelite Receiver	121
PROSAT	Sattelite Receiver	138
QUICK DRAW	Sattelite Receiver	144
RCA	Sattelite Receiver	110
RCA	Sattelite Receiver	116
RCA	Sattelite Receiver	118
RCA	Sattelite Receiver	141
RCA	Sattelite Receiver	233
RADIO SHACK	Sattelite Receiver	183
RADIO SHACK	Sattelite Receiver	196
RADIO SHACK	Sattelite Receiver	197
RADIO SHACK	Sattelite Receiver	225

Brand	Device_Type	Code_Number
RAMSEY	Sattelite Receiver	139
REALISTIC	Sattelite Receiver	225
REALISTIC	Sattelite Receiver	230
RURAL CABLE	Sattelite Receiver	196
SAMSUNG	Sattelite Receiver	108
STS	Sattelite Receiver	212
STS	Sattelite Receiver	213
SIERRA	Sattelite Receiver	216
SONY	Sattelite Receiver	112
SONY	Sattelite Receiver	114
STAR SIGHT	Sattelite Receiver	109
STAR TRAK	Sattelite Receiver	136
STAR TRAK	Sattelite Receiver	218
STAR TRAK	Sattelite Receiver	219
STAR TRAK	Sattelite Receiver	222
STAR TRAK	Sattelite Receiver	223
STRONG	Sattelite Receiver	136
SUPER GUIDE	Sattelite Receiver	253
TEE-COM	Sattelite Receiver	219
TEE-COM	Sattelite Receiver	223
TEE-COM	Sattelite Receiver	222
TEE-COM	Sattelite Receiver	264
TEE-COM	Sattelite Receiver	136
TOSHIBA	Sattelite Receiver	133
TOSHIBA	Sattelite Receiver	134
TOSHIBA	Sattelite Receiver	174
TOSHIBA	Sattelite Receiver	187
UNIDEN	Sattelite Receiver	117
UNIDEN	Sattelite Receiver	126
UNIDEN	Sattelite Receiver	135
UNIDEN	Sattelite Receiver	179
UNIDEN	Sattelite Receiver	180
UNIDEN	Sattelite Receiver	181
UNIDEN	Sattelite Receiver	182
UNIDEN	Sattelite Receiver	183
UNIDEN	Sattelite Receiver	184
UNIDEN	Sattelite Receiver	224
UNIDEN	Sattelite Receiver	225
UNIDEN	Sattelite Receiver	226
UNIDEN	Sattelite Receiver	227
UNIDEN	Sattelite Receiver	228
UNIDEN	Sattelite Receiver	230
UNIDEN	Sattelite Receiver	232
VIDEO CIPHER 2	Sattelite Receiver	186
VIDEO PALL	Sattelite Receiver	186
ZENITH	Sattelite Receiver	174
DIRECTV	Sattelite Receiver	257
HUGHES	Sattelite Receiver	30

Brand	Device_Type	Code_Number
HUGHES	Sattelite Receiver	267
Viewsat	Sattelite Receiver	278
DirecTV	Sattelite Receiver	151
Dish	Sattelite Receiver	271
Philips	Sattelite Receiver	273
SKY	Sattelite Receiver	274
SKY	Sattelite Receiver	274
Dish	Sattelite Receiver	271
Dish	Sattelite Receiver	303
DirecTV	Sattelite Receiver	93
LG	TV	290
ADMIRAL	TV	3
ADMIRAL	TV	18
ADMIRAL	TV	41
ADMIRAL	TV	90
ADMIRAL	TV	125
ADMIRAL	TV	129
ADMIRAL	TV	187
ADVENT	TV	257
ADVENT	TV	262
AIWA	TV	90
AIWA	TV	251
AKAI	TV	32
AKAI	TV	70
AKAI	TV	149
AKAI	TV	172
APEX	TV	12
APEX	TV	95
AUDIO	TV	238
AUDIOVOX	TV	24
AUDIOVOX	TV	41
AUDIOVOX	TV	120
AUDIOVOX	TV	170
BROKSONIC	TV	5
BROKSONIC	TV	23
BROKSONIC	TV	28
BROKSONIC	TV	172
BROKSONIC	TV	174
BROKSONIC	TV	176
CARVER	TV	151
CITIZEN	TV	5
CITIZEN	TV	6
CITIZEN	TV	16
CITIZEN	TV	18
CITIZEN	TV	22
CITIZEN	TV	23
CITIZEN	TV	24
CITIZEN	TV	26

Brand	Device_Type	Code_Number
CITIZEN	TV	150
CITIZEN	TV	163
CITIZEN	TV	172
CITIZEN	TV	202
CRAIG	TV	21
CRAIG	TV	41
CROWN	TV	26
CROWN	TV	41
CURTIS MATHES	TV	6
CURTIS MATHES	TV	16
CURTIS MATHES	TV	18
CURTIS MATHES	TV	26
CURTIS MATHES	TV	59
CURTIS MATHES	TV	90
CURTIS MATHES	TV	125
CURTIS MATHES	TV	131
CURTIS MATHES	TV	163
CURTIS MATHES	TV	172
CURTIS MATHES	TV	192
CURTIS MATHES	TV	194
CURTIS MATHES	TV	202
DAEWOO	TV	5
DAEWOO	TV	24
DAEWOO	TV	26
DAEWOO	TV	29
DAEWOO	TV	30
DAEWOO	TV	31
DAEWOO	TV	32
DAEWOO	TV	130
DAEWOO	TV	170
DAEWOO	TV	172
DAEWOO	TV	267
DAEWOO	TV	268
DAEWOO	TV	269
DAEWOO	TV	270
DAYTON	TV	1
DAYTON	TV	92
DAYTON	TV	194
DELL	TV	265
DENON	TV	169
EMERSON	TV	17
EMERSON	TV	20
EMERSON	TV	23
EMERSON	TV	26
EMERSON	TV	28
EMERSON	TV	33
EMERSON	TV	35
EMERSON	TV	36

Brand	Device_Type	Code_Number
EMERSON	TV	37
EMERSON	TV	38
EMERSON	TV	39
EMERSON	TV	41
EMERSON	TV	90
EMERSON	TV	122
EMERSON	TV	141
EMERSON	TV	143
EMERSON	TV	171
EMERSON	TV	172
EMERSON	TV	176
EMERSON	TV	181
EMERSON	TV	187
EMERSON	TV	203
EMERSON	TV	204
EMERSON	TV	205
ENVISION	TV	163
FISHER	TV	42
FISHER	TV	90
FISHER	TV	99
FUJITSU	TV	187
FUNAI	TV	41
FUNAI	TV	132
FUNAI	TV	187
GENERAL	TV	3
GENERAL	TV	8
GENERAL	TV	9
GENERAL	TV	23
GENERAL	TV	43
GENERAL	TV	44
GENERAL	TV	125
GENERAL	TV	130
GENERAL	TV	143
GENERAL	TV	147
GENERAL	TV	165
GENERAL	TV	170
GENERAL	TV	172
GENERAL	TV	182
GENERAL	TV	183
GENERAL	TV	195
GENERAL	TV	206
GENERAL	TV	207
GENERAL	TV	211
GO VIDEO	TV	260
GOLDSTAR	TV	5
GOLDSTAR	TV	23
GOLDSTAR	TV	26
GOLDSTAR	TV	28

Brand	Device_Type	Code_Number
GOLDSTAR	TV	45
GOLDSTAR	TV	46
GOLDSTAR	TV	151
GOLDSTAR	TV	168
GOLDSTAR	TV	172
GOLDSTAR	TV	194
GRUNDIG	TV	47
HIITACHI	TV	5
HIITACHI	TV	18
HIITACHI	TV	23
HIITACHI	TV	26
HIITACHI	TV	48
HIITACHI	TV	49
HIITACHI	TV	50
HIITACHI	TV	51
HIITACHI	TV	52
HIITACHI	TV	53
HIITACHI	TV	54
HIITACHI	TV	55
HIITACHI	TV	116
HIITACHI	TV	126
HIITACHI	TV	142
HIITACHI	TV	169
HIITACHI	TV	172
HIITACHI	TV	185
INFINITY/JBL	TV	10
INFINITY/JBL	TV	66
INFINITY/JBL	TV	151
JC PENNEY	TV	3
JC PENNEY	TV	5
JC PENNEY	TV	6
JC PENNEY	TV	14
JC PENNEY	TV	16
JC PENNEY	TV	26
JC PENNEY	TV	44
JC PENNEY	TV	96
JC PENNEY	TV	125
JC PENNEY	TV	131
JC PENNEY	TV	149
JC PENNEY	TV	163
JC PENNEY	TV	165
JC PENNEY	TV	172
JC PENNEY	TV	194
JC PENNEY	TV	202
JC PENNEY	TV	206
JC PENNEY	TV	207
JVC	TV	57
JVC	TV	58

Brand	Device_Type	Code_Number
JVC	TV	59
JVC	TV	60
JVC	TV	186
KENWOOD	TV	6
KONKA	TV	266
LUXMAN	TV	5
LUXMAN	TV	23
LUXMAN	TV	172
MAGNAVOX	TV	6
MAGNAVOX	TV	8
MAGNAVOX	TV	10
MAGNAVOX	TV	17
MAGNAVOX	TV	27
MAGNAVOX	TV	28
MAGNAVOX	TV	64
MAGNAVOX	TV	65
MAGNAVOX	TV	66
MAGNAVOX	TV	67
MAGNAVOX	TV	68
MAGNAVOX	TV	110
MAGNAVOX	TV	132
MAGNAVOX	TV	150
MAGNAVOX	TV	151
MAGNAVOX	TV	154
MAGNAVOX	TV	163
MAGNAVOX	TV	164
MAGNAVOX	TV	167
MAGNAVOX	TV	172
MAGNAVOX	TV	175
MAGNAVOX	TV	187
MAGNAVOX	TV	192
MAGNAVOX	TV	194
MAGNAVOX	TV	200
MEMOREX	TV	18
MEMOREX	TV	32
MEMOREX	TV	72
MEMOREX	TV	90
MEMOREX	TV	149
MEMOREX	TV	172
MEMOREX	TV	187
MGA	TV	4
MGA	TV	5
MGA	TV	6
MGA	TV	23
MGA	TV	71
MGA	TV	72
MGA	TV	149
MGA	TV	163

Brand	Device_Type	Code_Number
MGA	TV	172
MGA	TV	187
MGA	TV	192
MGA	TV	194
MIDLAND	TV	1
MIDLAND	TV	3
MIDLAND	TV	165
mitsubishi	TV	4
mitsubishi	TV	5
mitsubishi	TV	23
mitsubishi	TV	28
mitsubishi	TV	70
mitsubishi	TV	71
mitsubishi	TV	72
mitsubishi	TV	122
mitsubishi	TV	123
mitsubishi	TV	129
mitsubishi	TV	149
mitsubishi	TV	172
mitsubishi	TV	187
mitsubishi	TV	192
mitsubishi	TV	194
NEC	TV	5
NEC	TV	6
NEC	TV	7
NEC	TV	23
NEC	TV	28
NEC	TV	90
NEC	TV	163
NEC	TV	172
NEC	TV	183
NEC	TV	191
NEC	TV	192
NEC	TV	194
OPTIMUS	TV	90
OPTIMUS	TV	166
OPTIMUS	TV	196
ORION	TV	162
ORION	TV	176
ORION	TV	204
PANASONIC	TV	8
PANASONIC	TV	9
PANASONIC	TV	10
PANASONIC	TV	11
PANASONIC	TV	66
PANASONIC	TV	73
PANASONIC	TV	151
PANASONIC	TV	165

Brand	Device_Type	Code_Number
PANASONIC	TV	173
PANASONIC	TV	177
PANASONIC	TV	183
PANASONIC	TV	195
PANASONIC	TV	196
PANASONIC	TV	211
PHILCO	TV	5
PHILCO	TV	6
PHILCO	TV	64
PHILCO	TV	65
PHILCO	TV	67
PHILCO	TV	68
PHILCO	TV	110
PHILCO	TV	149
PHILCO	TV	150
PHILCO	TV	151
PHILCO	TV	163
PHILCO	TV	169
PHILCO	TV	172
PHILCO	TV	176
PHILCO	TV	183
PHILIPS	TV	5
PHILIPS	TV	10
PHILIPS	TV	27
PHILIPS	TV	66
PHILIPS	TV	68
PHILIPS	TV	146
PHILIPS	TV	150
PHILIPS	TV	151
PHILIPS	TV	163
PHILIPS	TV	164
PIONEER	TV	2
PIONEER	TV	8
PIONEER	TV	48
PIONEER	TV	51
PIONEER	TV	76
PIONEER	TV	131
PIONEER	TV	166
PROSCAN	TV	125
PROSCAN	TV	172
PROSCAN	TV	184
QUASAR	TV	8
QUASAR	TV	9
QUASAR	TV	165
QUASAR	TV	183
QUASAR	TV	195
QUASAR	TV	196
QUASAR	TV	211

Brand	Device_Type	Code_Number
RADIO SHACK	TV	3
RADIO SHACK	TV	26
RADIO SHACK	TV	28
RADIO SHACK	TV	41
RADIO SHACK	TV	72
RADIO SHACK	TV	90
RADIO SHACK	TV	112
RADIO SHACK	TV	141
RADIO SHACK	TV	172
RADIO SHACK	TV	194
RCA	TV	3
RCA	TV	5
RCA	TV	8
RCA	TV	14
RCA	TV	48
RCA	TV	78
RCA	TV	79
RCA	TV	80
RCA	TV	82
RCA	TV	84
RCA	TV	85
RCA	TV	86
RCA	TV	87
RCA	TV	125
RCA	TV	127
RCA	TV	130
RCA	TV	134
RCA	TV	149
RCA	TV	172
RCA	TV	182
RCA	TV	183
RCA	TV	210
REALISTIC	TV	35
REALISTIC	TV	41
REALISTIC	TV	90
REALISTIC	TV	141
REALISTIC	TV	172
REALISTIC	TV	194
SAMPO	TV	6
SAMPO	TV	19
SAMPO	TV	163
SAMPO	TV	188
SAMPO	TV	192
SAMPO	TV	194
SAMSUNG	TV	5
SAMSUNG	TV	6
SAMSUNG	TV	16
SAMSUNG	TV	23

Brand	Device_Type	Code_Number
SAMSUNG	TV	26
SAMSUNG	TV	28
SAMSUNG	TV	32
SAMSUNG	TV	112
SAMSUNG	TV	151
SAMSUNG	TV	163
SAMSUNG	TV	172
SAMSUNG	TV	192
SAMSUNG	TV	194
SAMSUNG	TV	202
SANSUI	TV	176
SANYO	TV	42
SANYO	TV	89
SANYO	TV	90
SANYO	TV	91
SANYO	TV	92
SANYO	TV	109
SANYO	TV	194
SEARS	TV	3
SEARS	TV	23
SEARS	TV	42
SEARS	TV	90
SEARS	TV	95
SEARS	TV	96
SEARS	TV	98
SEARS	TV	99
SEARS	TV	101
SEARS	TV	102
SEARS	TV	104
SEARS	TV	125
SEARS	TV	131
SEARS	TV	132
SEARS	TV	151
SEARS	TV	172
SEARS	TV	187
SEARS	TV	194
SEARS	TV	201
SEARS	TV	202
SHARP	TV	26
SHARP	TV	91
SHARP	TV	129
SHARP	TV	141
SIGNATURE	TV	18
SONY	TV	109
SONY	TV	119
SONY	TV	122
SONY	TV	189
SONY	TV	200

Brand	Device_Type	Code_Number
SOUNDESIGN	TV	23
SOUNDESIGN	TV	41
SOUNDESIGN	TV	150
SOUNDESIGN	TV	172
SOUNDESIGN	TV	187
SYLVANIA	TV	6
SYLVANIA	TV	10
SYLVANIA	TV	28
SYLVANIA	TV	64
SYLVANIA	TV	65
SYLVANIA	TV	66
SYLVANIA	TV	68
SYLVANIA	TV	110
SYLVANIA	TV	112
SYLVANIA	TV	132
SYLVANIA	TV	150
SYLVANIA	TV	151
SYLVANIA	TV	163
SYLVANIA	TV	172
SYLVANIA	TV	192
SYLVANIA	TV	194
SYLVANIA	TV	263
TANDY	TV	112
TANDY	TV	113
TANDY	TV	129
TATUNG	TV	9
TATUNG	TV	159
TATUNG	TV	183
TATUNG	TV	211
TECHNICS	TV	8
TECHNICS	TV	165
TECHNICS	TV	196
THOMSON	TV	51
THOMSON	TV	116
THOMSON	TV	142
TOSHIBA	TV	16
TOSHIBA	TV	17
TOSHIBA	TV	47
TOSHIBA	TV	90
TOSHIBA	TV	96
TOSHIBA	TV	118
TOSHIBA	TV	131
TOSHIBA	TV	180
TOSHIBA	TV	201
TOSHIBA	TV	202
TOTEVISION	TV	26
VIEWSONIC	TV	261
WARDS	TV	5

Brand	Device_Type	Code_Number
WARDS	TV	6
WARDS	TV	18
WARDS	TV	23
WARDS	TV	28
WARDS	TV	44
WARDS	TV	64
WARDS	TV	65
WARDS	TV	67
WARDS	TV	68
WARDS	TV	119
WARDS	TV	125
WARDS	TV	141
WARDS	TV	151
WARDS	TV	163
WARDS	TV	172
WARDS	TV	182
WARDS	TV	187
WARDS	TV	192
WARDS	TV	194
WARDS	TV	206
WARDS	TV	207
WESTINGHOUSE	TV	41
WESTINGHOUSE	TV	90
WESTINGHOUSE	TV	130
WESTINGHOUSE	TV	170
WESTINGHOUSE	TV	171
WESTINGHOUSE	TV	176
WESTINGHOUSE	TV	204
WESTINGHOUSE	TV	258
YAMAHA	TV	5
YAMAHA	TV	6
ZENITH	TV	1
ZENITH	TV	18
ZENITH	TV	24
ZENITH	TV	40
ZENITH	TV	178
ZENITH	TV	264
APEX	TV	201
Disney	TV	274
Dell	TV	276
Durabrand	TV	274
Durabrand	TV	274
JVC	TV	279
Magnavox	TV	281
Durabrand	TV	176
Polariod	TV	295
LG	TV	290
SAMSUNG	TV	280

Brand	Device_Type	Code_Number
Dynex	TV	299
Olevia	TV	300
Nexus	TV	299
Tatung	TV	303
Panasonic	TV	73
Olevia	TV	300
Durabrand	TV	277
Bell	TV	284
Insignia	TV	286
Samsung	TV	287
Samsung	TV	288
Magnavox	TV	291
Magnavox	TV	292
Sears	TV	057
Samsung	TV	293
Tatung	TV	303
Hallmark	TV	23
Hinari	TV	34
Jensen	TV	56
KTV	TV	26
KTV	TV	39
KTV	TV	41
KTV	TV	172
Kawasho	TV	61
Kloss	TV	22
LXI	TV	3
LXI	TV	66
LXI	TV	90
LXI	TV	117
LXI	TV	125
LXI	TV	131
LXI	TV	172
LXI	TV	173
Lodgenet	TV	18
Logik	TV	18
MTC	TV	5
MTC	TV	6
MTC	TV	16
MTC	TV	23
MTC	TV	31
MTC	TV	163
TCL	TV	304
Magnavox	TV	164
Sylvania	TV LCD	297
Sylvania	TV LCD	297
Vizio	TV LCD	290
Vizio	TV LCD	172
Westinghouse	TV LCD	282

Brand	Device_Type	Code_Number
Insignia	TV LCD	285
ILO	TV LCD	294
Sanyo	TV LCD	90
Teac	TV LCD	296
Westinghouse	TV LCD	200
Samsung	TV LCD	306
Samsung	TV LCD	307
Samsung	TV LCD	308
Samsung	TV LCD	309
Vizio	TV LCD	310
WESTINGHOUSE	TV LCD	192
Samsung	TV Plasma	280
Apex	TV/DVD	15
Magnavox	TV/DVD	34
Philips	TV/DVD	63
Sylvania	TV/DVD	69
Toshiba	TV/DVD	74
Sylvania	TV/DVD	274
Sylvania	TV/DVD	274
Broksonic	TV/DVD	278
Broksonic	TV/DVD	278
Sylvania	TV/DVD	273
Sylvania	TV/DVD	273
Emerson	TV/DVD	273
Emerson	TV/DVD	273
Samsung	TV/DVD	280
Samsung	TV/DVD	280
Sylvania	TV/DVD	275
Insignia	TV/DVD	283
Haier	TV/DVD	257
LXI	TV/VCR	223
LXI	TV/VCR	251
LXI	TV/VCR	254
Aiwa	TV/VCR	251
Audio Dynamics	TV/VCR	238
Broksonic	TV/VCR	219
Curtis Mathes	TV/VCR	231
DBX	TV/VCR	238
Daewoo	TV/VCR	247
Electrohome	TV/VCR	240
Emerson	TV/VCR	219
Funai	TV/VCR	251
General Electric	TV/VCR	231
Goldstar	TV/VCR	223
Harman Kardon	TV/VCR	238
Hitachi	TV/VCR	231
JC Penney	TV/VCR	223
JVC	TV/VCR	234

Brand	Device_Type	Code_Number
Kenwood	TV/VCR	235
MGA	TV/VCR	240
Magnavox	TV/VCR	231
Marantz	TV/VCR	237
Marta	TV/VCR	223
Memorex	TV/VCR	223
Mitsubishi	TV/VCR	239
Optimus	TV/VCR	242
Orion	TV/VCR	219
Panasonic	TV/VCR	231
Philco	TV/VCR	236
Philips	TV/VCR	223
Pioneer	TV/VCR	235
Proscan	TV/VCR	233
Pulsar	TV/VCR	248
Quasar	TV/VCR	231
RCA	TV/VCR	231
Radio Shack	TV/VCR	230
Realistic	TV/VCR	223
Runco	TV/VCR	243
Samsung	TV/VCR	221
Sansui	TV/VCR	219
Sanyo	TV/VCR	244
Scott	TV/VCR	247
Sears	TV/VCR	223
Signature	TV/VCR	251
Sony	TV/VCR	232
Soundesign	TV/VCR	251
Sylvania	TV/VCR	237
Symphonic	TV/VCR	251
Tandy	TV/VCR	251
Teac	TV/VCR	251
Technics	TV/VCR	242
Teknika	TV/VCR	223
Toshiba	TV/VCR	240
Totevision	TV/VCR	223
Vector Research	TV/VCR	238
Broksonic	TV/VCR	226
Curtis Mathes	TV/VCR	241
Daewoo	TV/VCR	250
Emerson	TV/VCR	223
General Electric	TV/VCR	233
Goldstar	TV/VCR	230
Hitachi	TV/VCR	241
JC Penney	TV/VCR	231
JVC	TV/VCR	235
Kenwood	TV/VCR	251
Magnavox	TV/VCR	236

Brand	Device_Type	Code_Number
Marantz	TV/VCR	238
Memorex	TV/VCR	242
Mitsubishi	TV/VCR	240
Orion	TV/VCR	226
Panasonic	TV/VCR	241
Philco	TV/VCR	237
Philips	TV/VCR	236
Quasar	TV/VCR	241
RCA	TV/VCR	233
Radio Shack	TV/VCR	242
Realistic	TV/VCR	251
Samsung	TV/VCR	244
Sansui	TV/VCR	235
Sanyo	TV/VCR	245
Sylvania	TV/VCR	240
Teknika	TV/VCR	251
Toshiba	TV/VCR	247
Daewoo	TV/VCR	252
Emerson	TV/VCR	226
General Electric	TV/VCR	241
Goldstar	TV/VCR	238
Hitachi	TV/VCR	251
JC Penney	TV/VCR	238
JVC	TV/VCR	238
Magnavox	TV/VCR	237
Memorex	TV/VCR	244
Panasonic	TV/VCR	242
Philco	TV/VCR	251
Philips	TV/VCR	237
Quasar	TV/VCR	242
RCA	TV/VCR	241
Samsung	TV/VCR	245
Sylvania	TV/VCR	251
Emerson	TV/VCR	251
General Electric	TV/VCR	248
Goldstar	TV/VCR	254
JC Penney	TV/VCR	241
Magnavox	TV/VCR	241
Philips	TV/VCR	251
RCA	TV/VCR	251
Samsung	TV/VCR	246
Emerson	TV/VCR	253
JC Penney	TV/VCR	242
Magnavox	TV/VCR	251
Memorex	TV/VCR	248
Samsung	TV/VCR	247
Memorex	TV/VCR	251
White	TV/VCR	251

Brand	Device_Type	Code_Number
Magnavox	TV/VCR/DVD	273
BROKSONIC	TVVCR	219
BROKSONIC	TVVCR	226
CITIZEN	TVVCR	224
CURTIS MATHES	TVVCR	224
CURTIS MATHES	TVVCR	231
DAEWOO	TVVCR	224
DAEWOO	TVVCR	247
DAEWOO	TVVCR	250
DAEWOO	TVVCR	252
ELECTROHOME	TVVCR	224
ELECTROHOME	TVVCR	240
EMERSON	TVVCR	219
EMERSON	TVVCR	222
EMERSON	TVVCR	223
EMERSON	TVVCR	224
EMERSON	TVVCR	225
EMERSON	TVVCR	226
EMERSON	TVVCR	227
EMERSON	TVVCR	251
EMERSON	TVVCR	253
FUNAI	TVVCR	251
GENERAL	TVVCR	231
GENERAL	TVVCR	233
GENERAL	TVVCR	248
GOLDSTAR	TVVCR	223
GOLDSTAR	TVVCR	224
GOLDSTAR	TVVCR	225
GOLDSTAR	TVVCR	230
GOLDSTAR	TVVCR	238
GOLDSTAR	TVVCR	254
HARMON	TVVCR	238
HITACHI	TVVCR	224
HITACHI	TVVCR	225
HITACHI	TVVCR	231
HITACHI	TVVCR	241
HITACHI	TVVCR	251
JC PENNEY	TVVCR	223
JC PENNEY	TVVCR	224
JC PENNEY	TVVCR	231
JC PENNEY	TVVCR	238
JC PENNEY	TVVCR	241
JC PENNEY	TVVCR	242
JVC	TVVCR	234
JVC	TVVCR	235
JVC	TVVCR	238
KENWOOD	TVVCR	235
KENWOOD	TVVCR	251

Brand	Device_Type	Code_Number
MAGNAVOX	TVVCR	224
MAGNAVOX	TVVCR	225
MAGNAVOX	TVVCR	231
MAGNAVOX	TVVCR	236
MAGNAVOX	TVVCR	237
MAGNAVOX	TVVCR	241
MAGNAVOX	TVVCR	251
MARANTZ	TVVCR	237
MARANTZ	TVVCR	238
MEMOREX	TVVCR	223
MEMOREX	TVVCR	242
MEMOREX	TVVCR	244
MEMOREX	TVVCR	245
MEMOREX	TVVCR	248
MEMOREX	TVVCR	251
MGA	TVVCR	240
mitsubishi	TVVCR	239
MITSUBISHI	TVVCR	240
OPTIMUS	TVVCR	242
ORION	TVVCR	219
ORION	TVVCR	226
PANASONIC	TVVCR	231
PANASONIC	TVVCR	241
PANASONIC	TVVCR	242
PHILCO	TVVCR	224
PHILCO	TVVCR	225
PHILCO	TVVCR	236
PHILCO	TVVCR	237
PHILCO	TVVCR	251
PHILIPS	TVVCR	220
PHILIPS	TVVCR	223
PHILIPS	TVVCR	225
PHILIPS	TVVCR	236
PHILIPS	TVVCR	237
PHILIPS	TVVCR	251
PIONEER	TVVCR	235
PULSAR	TVVCR	248
QUASAR	TVVCR	231
QUASAR	TVVCR	241
QUASAR	TVVCR	242
RADIO SHACK	TVVCR	224
RADIO SHACK	TVVCR	229
RADIO SHACK	TVVCR	230
RADIO SHACK	TVVCR	242
RCA	TVVCR	231
RCA	TVVCR	233
RCA	TVVCR	241
RCA	TVVCR	251

Brand	Device_Type	Code_Number
REALISTIC	TVVCR	222
REALISTIC	TVVCR	223
REALISTIC	TVVCR	224
REALISTIC	TVVCR	229
REALISTIC	TVVCR	251
SAMSUNG	TVVCR	221
SAMSUNG	TVVCR	224
SAMSUNG	TVVCR	225
SAMSUNG	TVVCR	229
SAMSUNG	TVVCR	244
SAMSUNG	TVVCR	245
SAMSUNG	TVVCR	246
SAMSUNG	TVVCR	247
SANSUI	TVVCR	219
SANSUI	TVVCR	235
SANYO	TVVCR	244
SANYO	TVVCR	245
SEARS	TVVCR	223
SEARS	TVVCR	224
SEARS	TVVCR	225
SHARP	TVVCR	224
SHARP	TVVCR	225
SHARP	TVVCR	255
SIGNATURE	TVVCR	251
SONY	TVVCR	200
SOUNDESIGN	TVVCR	251
SYLVANIA	TVVCR	229
SYLVANIA	TVVCR	237
SYLVANIA	TVVCR	240
SYLVANIA	TVVCR	251
SYMPHONIC	TVVCR	251
TANDY	TVVCR	251
TEAC	TVVCR	251
TECHNICS	TVVCR	242
TOSHIBA	TVVCR	240
TOSHIBA	TVVCR	247
TOTEVISION	TVVCR	223
TOTEVISION	TVVCR	224
WARDS	TVVCR	224
WARDS	TVVCR	251
YAMAHA	TVVCR	238
YAMAHA	TVVCR	251
ZENITH	TVVCR	219
ZENITH	TVVCR	223
ZENITH	TVVCR	235
ZENITH	TVVCR	248
ZENITH	TVVCR	251