

APPLICATIONS NOTE:

WEEMOTE TV REMOTE CONTROLS SEARCHING FOR YOUR CODE

Please note the following instructions on how to search for a code for your TV or Set-Top device. *Note that these code search instructions only apply to weemote® TV remote control products with a product code version 7 or later.*

Please note that code search instructions can also be found on Page 6 of the weemote® Reference Guide and Speed Adjustment instructions can be found in Page 15 of the same guide.

FOR TV CODE SEARCHING (TV, TV/VCR, TV/DVD, TV/VCR/DVD) – USE THE A BUTTON – STEP 2A

FOR SET-TOP DEVICE CODE SEARCHING (CABLE BOX, SATELITTE RECEIVER, TIVO, IPTV RECEIVER) – USE THE B BUTTON – STEP 2B

1. Turn Your TV or SET-TOP DEVCE ON

2a. FOR TV CODE SEARCH: Press and Hold the A button for about 3 seconds until the LED light turns on GREEN, then release the A Button.

2b. FOR SET-TOP CODE SEARCH: Press and Hold the B button for about 3 seconds until the LED light turns on GREEN, then release the B Button.

3. While pointing the weemote® directly at your TV, slowly (about every .5 second), press and release the VOL+ button (The top portion of the YELLOW button). When you do this, the LED light should go off when the button is pressed down and on bright again when you release the button.

HINT: You can press and release the Vol - button to go backwards.

4. When the TV responds by turning off, press and release the RED Power button to see if you can get the TV to turn back on.

4a. If the TV turns back on, press and release the A button to lock in this code into your weemote®.

4b. If the TV does not turn back on, go to your TV set and turn it back on, then resume the code search process as described in Step 3.

4c. If the TV turned OFF and if you feel you pressed the VOL+ button a few more times after it turned off, press and release the VOL- button to see if you can get it to turn back on. If it turns back on, press and release the A button to lock in the code. If it did not turn back on, go back to Step 4b and resume your code search.

5. If you reach the end of all the codes available to be searched in the weemote, the LED light will flash quickly. If you don't see the LED flash quickly and you have pressed the button about 120 times, then you have probably searched all the codes available. If this happens in your case, you have one more option to try. See Step 6.

6. If you performed a complete code search and could not find a working code, it sometimes helps to speed up the timing in the weemote to find a proper code. It works best

to set the speed of the weemote to the fastest possible setting. To set the speed to the fastest possible setting.

- 6a. Press and Hold the B button for about 3 seconds until the LED light turns on GREEN, then release the B Button.
- 6b. Press and release the Gray MUTE button. The LED light should blink once.
- 6c. Press and release the small #1 program button. The LED light should blink three times and go out to confirm your new setting.
- 6d. Now go back to Step 1 to try the code search again.

7. If after all this you still can't find a matching code, then please notify us of your brand and model number of your device. There may be either a later product code version currently shipping that supports your device or we may issue a future update. Contact us at info@fobis.com to see if an update is available or pending to support your device.

IF YOU DO FIND A MATCHING CODE, PLEASE LET US KNOW ALONG WITH YOUR BRAND AND MODEL NUMBER SO WE CAN RECORD THAT HERE FOR FUTURE CUSTOMER INQUIRIES. Thank You.